

1 Before driving

- | | |
|---|--|
| <p>1-1. Hybrid system
 Hybrid system..... 34</p> <p>1-2. Key information
 Keys 47</p> <p>1-3. Opening, closing and locking the doors and trunk
 Smart access system with push-button start 52
 Wireless remote control..... 65
 Doors..... 68
 Trunk..... 73</p> <p>1-4. Adjustable components (seats, mirrors, steering wheel)
 Front seats..... 80
 Power rear seat..... 86
 Driving position memory 96
 Rear seat position memory 102
 Head restraints..... 104
 Seat belts 107
 Steering wheel..... 114
 Anti-glare inside rear view mirror 115
 Outside rear view mirrors..... 117</p> | <p>1-5. Opening and closing the windows and moon roof
 Power windows..... 119
 Moon roof 122</p> <p>1-6. Refueling
 Opening the fuel tank cap..... 126</p> <p>1-7. Theft deterrent system
 Immobilizer system 131
 Alarm..... 133</p> <p>1-8. Safety information
 Correct driving posture 136
 SRS airbags 138
 Front passenger occupant classification system..... 152
 Child restraint systems 157
 Installing child restraints..... 162</p> |
|---|--|

2 When driving

2-1. Driving procedures

Driving the vehicle.....	174
Power (ignition) switch.....	183
EV drive mode.....	187
Transmission.....	189
Turn signal lever.....	194
Parking brake.....	195
Brake Hold.....	197
Horn.....	199

2-2. Instrument cluster

Gauges and meters.....	200
Indicators and warning lights.....	205
Multi-information display.....	209

2-3. Operating the lights and windshield wipers

Headlight switch.....	213
Automatic High Beam.....	216
Fog light switch.....	221
Windshield wipers and washer.....	222
Headlight cleaner switch.....	225

2-4. Using other driving systems

Cruise control.....	226
Dynamic radar cruise control.....	230
Intuitive parking assist.....	243
LKA (Lane-Keeping Assist).....	251
Electronically modulated air suspension.....	258
Advanced parking guidance system.....	260
Driving assist systems.....	301
Pre-Collision System.....	308

2-5. Driving information

Cargo and luggage.....	318
Vehicle load limits.....	321
Winter driving tips.....	323
Trailer towing.....	327
Dinghy towing.....	328

3 Interior features

3-1. Using the touch screen

Touch screen	330
Set up screen	331
Information screen	332

3-2. Using the air conditioning system and defogger

Front air conditioning system	333
Rear air conditioning system	347
Rear window and outside rear view mirror defoggers	355
Windshield wiper de-icer	356

3-3. Using the interior lights

Interior lights list	357
• Interior lights	358
• Personal lights	359

3-4. Using the storage features

List of storage features	361
• Glove box	363
• Coin holder	364
• Door pockets	364
• Cup holders	365
• Console box	366
• Non smokers boxes	368
• Auxiliary boxes	369

3-5. Other interior features

Sun visors	372
Vanity mirrors	373
Outside temperature display	374
Ashtrays	375
Cigarette lighters	376
Power outlets	378
Heated steering wheel	381
Climate control seats/seat heaters	383
Armrest	387
Retractable table	388
Rear sunshade	390
Rear door sunshades	393
Coat hooks	396
Floor mat	397
Trunk features	398
Garage door opener	400
Safety Connect	406

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior	414
Cleaning and protecting the vehicle interior	417

4-2. Maintenance

Maintenance requirements	420
General maintenance	422
Emission inspection and maintenance (I/M) programs	425

4-3. Do-it-yourself maintenance

Do-it-yourself service precautions	426
Hood	429
Positioning a floor jack	430
Engine compartment	432
12-volt battery	444
Tires	448
Tire inflation pressure	457
Wheels	461
Air conditioning filter	463
Electronic key battery	466
Checking and replacing fuses	468
Headlight aim	474
Light bulbs	476

5 When trouble arises

5-1. Essential information

Emergency flashers	488
If your vehicle needs to be towed	489
If you think something is wrong	495
Event data recorder	496

5-2. Steps to take in an emergency

If a warning light turns on or a warning buzzer sounds... ..	498
If a warning message is displayed	508
If you have a flat tire	511
If the hybrid system will not start	519
If the shift lever cannot be shifted from "P"	521
If the parking brake cannot be released	522
If the electronic key does not operate properly	524
If the 12-volt battery is discharged	527
If your vehicle overheats	530
If the vehicle becomes stuck	534
If your vehicle has to be stopped in an emergency	535

6

Vehicle specifications

6-1. Specifications

Maintenance data
 (fuel, oil level, etc.)..... 538

Fuel information..... 551

Tire information..... 554

6-2. Customization

Customizable features..... 565

7

For owners

Reporting safety defects
 for U.S. owners..... 576

Seat belt instructions
 for Canadian owners
 (in French)..... 577

SRS airbag instructions
 for Canadian owners
 (in French)..... 579

Index

Abbreviation list..... 590

Alphabetical index 592

What to do if... 604

1

2

3

4

5

6

7